

## Installation of Polyurethane Accents & Mouldings

Use construction adhesives such as **PL Premium** or **Liquid Nails** (available at Home Depot and other hardware stores) for gluing the polyurethane mouldings and accents to the substrate.

### PL Premium:



<http://www.lepageproducts.com/products/detail.asp?catid=22&subid=108&plid=284>

### Liquid Nails:



<http://www.liquidnails.com/ViewProductDetails.do?productId=54>

**See the manufacturers instructions to make sure that the construction glue is suitable for bonding both to your substrate and polyurethane foam.**

Use mechanical fasteners such as stainless steel screws to secure the mouldings where possible.